















**DANCOVER<sup>®</sup>**









Manual  
Party tent  
5m Series PE

# Part list for 5m PE Party Tent


Part No.		6m	8m	10m	12m
1	 510mm	8	10	12	14
2	 1940mm	17	22	27	32
4	 1880mm	8	10	12	14
5		8	10	12	14
6	 110°	4	4	4	4
7	 110°	4	6	8	10
8	 140°	2	2	2	2
9	 140°	2	3	4	5
10		4	4	4	4
12		8	10	12	14
13		8	10	12	14
14		32	36	40	44
15		66	84	102	120
16		68	76	84	92

# Part list for 5m PE Party Tent



Part No.		6m	8m	10m	12m
17		4	4	4	4
18		1	1	1	1
19		2	2	2	2
20		1	1	1	1
21		1	1	1	1




**A**




# B








# C



# D



# E



# F

